



If you are purchasing this kit from Industrial Chassis Inc. with spindles, no further modification is needed. If you are installing this kit on a previously purchased spindles, it is necessary to drill out the tie - rod end taper to 5/8". Use RED Loctite or equivalent thread locker on the heim to sleeve connection and install the tie rod end onto the tie rod as normal. Assemble the kit as shown and torque the attachment bolt to 150+ ft/lbs of torque and insert a cotter pin. Align the suspension after installation to 1994-1996 Dodge - Dakota specifications.

0150 and 0160 Dropped steering arm kit
any

0150 and 0160 Dropped steering arm kit

